

ACTIVATING DEA ROLLING CODE CONTROLS

DEA receivers can operate in fixed or rolling code mode. The different modes can be selected by placing a jumper in some specific positions. The jumper can be found in the middle of the electronic board and the positions are marked on the board as A (for the fixed position) or B (for the rolling code position).

Procedua daliinskog programiranja

1. Ispred prijemnika pritisite obje tipke na već programiranom daljincu i držite.

LED dioda se osvjetljuje kako bi se indiciralo da je proces programiranja započeo.

2. Pritisnite tipku na daljincu koji želite aktivirati unutar 5sek.

LED dioda ne prijemniku će bljesnuti i ugasi se, pokazujuću da je programiranje uspješno

Procedura prijavljivanja unutar prijemnika

1. Unutar prijemnika pritisite i pusite tipku P1 ispod LED diode.

LED dioda se pali i proces programiranja je započet.

2. Pritisnite tipku na novom daljincu kojeg želite prijaviti.

LED dioda će bljesnuti kako bi ukazala da je daljinac programiran.

3. Proramiranje je uspješno izvršeno. Ponovi korak 2 za prijavu dodatnih daljinaca
Kada se LED dioda ugasi proces programiranja je završen.

NAPOMENA!!!

AKO TIPKU UNUTAR PRIJEMNIKA DRŽITE PRITISNUTU DUŽE OD 5sek BRIŠU SE SVI DALJINSKI UPRAVLJAČI PRIJAVLJENI DO SADA.

