

PROCEDURA PROGRAMIRANJA

ROLLING CODE BRANDS	NEEDED TRANSMISSIONS TO COPY	AUTOMATIC RECORDING ON RECEIVER BY KEEPING THE BUTTON PRESSED
JCM 1ª GEN	2	YES
MUTANCODE	2	YES
PUJOL VARIO	1	YES
ROPER	2	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
CELINSA	1	YES
GIBIDI	1	YES
DEA	1	YES
SMILO	1	YES
DOORMATIC	1	YES
JCM 2ª GEN	2	YES
BENINCA/ALLMATIC/EUROPE AUTOMATISME	1	YES
SEAV	1	YES
ERREKA	2(1+PROGRAMMING BUTTON)	YES
BFT	2(1+PROGRAMMING BUTTON)	YES
APRIMATIC TR	1	YES
NICE FLOR (No perso)	1	YES
V2	1	CLONE. IT WORKS WITHOUT PROGRAMMING
APRIMATIC TXM (No perso)	1	YES
FAAC (Only Master)	2(1+PROGRAMMING BUTTON)	IT WORKS WITHOUT PROGRAMMING
DITEC	1	CLONE. IT WORKS WITHOUT PROGRAMMING
AERF	2	YES
PRASTEL TP2E (No perso)	1	YES
ROLLTORE TP2E (No perso)	1	YES
FADINI	1	YES
KEY	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
MHOUSE	1	YES
NOVOFERM	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
LIFT MASTER /CHAMBERLAIN	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
SOMMER (FM)	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
CARDIN S449 (FM)	1	YES
TELCOMA FM 402 (FM)	2	YES
GENIUS / ADYX	1	YES
ECOSTAR	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
SOMFY KEYTIS / TELIS	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
MOTORLINE	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
CAME ATO	1	YES
SKYMASTER	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
AVIDSEN	1	CLONE. IT WORKS WITHOUT PROGRAMMING
GENIE	2	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING
CARDIN S435	1	RECEIVER DOES NOT ALLOW RADIO PROGRAMMING

GUMBI ZA PROGRAMIRANJE

•Kod BFT ili ERREKA daljinca, gumb za programiranje je skriveni gumb ili u isto vrijeme pritisnuti dva gumba na originalnom daljincu..

•Kod FAAC daljinca Master, frame za programiranje se šalje :

- U isto vrijeme pritisnuti 1 i 2 gumb na originalnom daljincu.
- Kada LEDica počne treptati pritisnite tipku na originalnom daljincu.Kopiranje ovog daljinca radi se gumb po gumb.

AUTOMATSKO SNIMANJE NA PRIJEMNIKU :

Na nekim prijemnicima:

1. Ako je slobodna memorija
2. Ako je aktiviran radio mod

Moguće je aktivirati M-FR1 tako što pritisnete već kopirani gumb na 10 sekundi. Tada počinje proces programiranja i M-FR1 će par puta promijeniti LED boju dok se ne ugasi.

U tablici vidite mogućnosti.

UPOZORENJE : nemaju svi prijemnici istog proizvođača tu mogućnost.



www.jma.es